

FIREXO EXTINGUISHER TRANSPORT BRACKET RANGE

Extinguisher Size	1L	1.4L	1.75L	2L	2.4L	6L	9L
Bracket Weight (g)	218	232	246	250	262	355	394
Bracket Height (mm)	268	245	285	317	255	430	500
Bracket Width (mm)	80	96	96	96	110	142	142
Bracket Depth (mm)	95	121	121	121	151	173	195
Material	Black aluminium frame with quick release steel straps.						



- Remove black base from the fire extinguisher
- Secure bracket to wall and/or suitable surface using fixings that will support the weight of the bracket and fire extinguisher
- If hose is fitted to the fire extinguisher, ensure hose is on outside of quick release straps
- Place extinguisher into the bracket
- Ensure the pressure gauge is facing forwards
- Secure and clip together the quick release straps
- If hose is fitted to the fire extinguisher, re-secure hose over the straps



© FIREXO 2022 This data specification sheet provides guidance only. It does not represent scientific or professional advice to any recipient or third party reader. Whilst great care has been taken to compile accurate data herein, FIREXO does not accept any responsibility or legal liability for any errors or omissions.